

HITROL CO., LTD.


HEAD OFFICE.FACTORY R&D INSTITUTE
HITROL CO., LTD. 141, Palhakgol-gil, Jori-eup
Paju-si, Gyeonggi-do, Korea
TEL.: (+82)-31-950-9700
FAX: (+82)-31-943-5600
www.hitrol.com



INSTRUCTION MANUAL

QUICK FLOAT TYPE LEVEL SWITCH

HQM(HQ) Series



Doc. no. : HQM(HQ)_IM_Eng_Rev.5.0

Issue date: 2025. 05

Table of contents

Overview	3
Characteristics	3
Operating Principles	3
Micro Switch	3
Mercury Switch	3
Specifications	4
Product Components	5
Dimensions	6
Wiring	7
HLC-Series Wiring and Precaution	7
Operation Position Adjustment	7
Maintenance	8
Precautions for Installation	8
Precautions for Removal	9
Safety and Environment	9
Marking	9
User Training	10
Warranty and Contact	10



You shall be well-informed of the contents where **WARNING** is marked before carrying out the work.



You shall be careful where **CAUTION** is marked to carry out the work.



You shall be aware of where **NOTICE** is marked to carry out the work.

Overview

The HQM(HQ) Series is a float-type level switch, which is solid and easy to use. It is designed to control different liquid levels in boilers as well as water treatment and other industrial facilities.

Characteristics

- Its simple shape and structure ensures easy installation and long service life.
- As it is a cable type, it enables usage in wastewater with floating matters or high-density liquid.
- It has no exposed metal part, which makes it resistant to corrosion (except for the SUS Float Type).
- It is easy to adjust the operation switch locally.


Operating Principles

■ Micro Switch

As the liquid level rises, the float also rises because of its buoyancy thus causing it to tilt. The metal ball inside presses the micro switch to make contact.

■ Mercury Switch (Only HQ-66S)

As the liquid level rises, the float also rises because of its buoyancy thus causing it to tilt. As such, the mercury inside the float flows to the terminal to connect it as a contact.



<Internal Structure of the Micro S/W Float> <Internal Structure of the Mercury S/W Float>

Specifications


Model	HQM-36	HQM-77	HQ-66S
Mounting	Flange		
Enclosure	Weather-proof		
	IP54(Std.) IP65(Opt.)		IP54
Temperature	Max. 60°C		Max. 150°C
Process Pressure	ATM		
Switch Type	Micro Switch		Mercury Switch
Contact Rating	AC 250V, 3A / AC 125V, 5A DC 30V, 0.1A(Opt.)		AC 110V, 1A / DC 24V, 0.5A
Contact Form	SPDT		SPST(Std.), SPDT(Opt.)
Head Material	ABS(Std.), 304 SS(Opt.)		304 SS
Cable Entry	ABS: PF 1/2"(F), 304 SS: 20A Cable Connector		
Process Connection	80A JIS 10K FF	100A JIS 10K FF	100A JIS 10K RF
Flange Material	PVC		304 SS, 316L SS
Float Material	ABS		316L SS
Cable Material	NBR	NBR(Std.), PUR(Opt.)	Silicon
Guide Wire Material	Nylon		304 SS, 316 SS
Weight Material	CS+ABS		304 SS
Weight Size	1,2F: Ø55 x 60L 3,4F: Ø70 x 70L		76.3 x 80L
Measuring Length	6m(Std.)		
Application	물, 오페수	물, 오페수 (Cable: NBR) 기름, 용매 (Cable: PUR)	보일러 응축수, 고온오페수
Combination Unit	HLC-200A, HLC-300N, or HLC-400		




NOTICE

The HQM(HQ) Series recommends working with our Combination Unit as arc phenomena may cause malfunction and damage to parts, and guides you that you cannot be responsible for the warranty caused by failure to meet them.


Product Components




Dimensions




HQ-36
(ABS Housing)




HQM-77
(ABS Housing)




HQ-66S
(SUS Housing)



HQM-3



HQM-7



HQ-6S



NOTICE

Some tolerances may occur with actual products.

Wiring

■ Components

- Open the cover and insert the cable into the inlet.
- Find the contact cable (E1, E2 ...) that you want and connect it.
- Install an electrical spring connector and then use a tool to press it.

■ Terminal Block (Opt.)

- Open the cover and insert the cable into the inlet.
- Check the contact identification of the terminal block (E1, E2 ...) and connect it.



[Fig. 1 Terminal Block 8P]

● Wiring Diagram ex)

2-SPDT: C-1 A-1 B-1 C-2 A-2 B-2 (6P)

4-SPDT: C-1 A-1 C-2 A-2 C-3 A-3 C-4 A-4 (8P)

● Wire Color

Contact C – Black / Contact A – White / Contact B – Red



3-SPDT or more contact points are restricted for the 8P terminal block, so connect it to contact A or B according to requirements.

HLC-Series Wiring and Precaution

Since the HQM(HQ) Series only transmits contact signals, it is recommended to use it with the control unit HLC-Series to perform control and alarm functions.

The HLC-Series is divided into HLC-200A (H/L Control), HLC-300N (H Alarm, H/L Control, L Alarm) and HLC-400 (4-Alarm) depending on the application. The user can apply the appropriate control unit.



HLC-Series is not an explosion proof product and must be installed and operated in a non-explosive area.

Operation Position Adjustment

- Take out the product from the container and open the cover.
- Release the cable gland and then cut the cable tie. Try not to cause damage to the cable or guide wire while cutting the cable tie.
- Adjust the cable as you want under the flange.
- Tighten the cable gland to seal the container.
- If the cable is too long, cut it appropriately and then connect it.
- Tie the cable with a guide wire using a cable tie. Keep it at about 100 mm away from the float or the float will not work.

Maintenance

The float and switches are important parts to be inspected for the HQM(HQ)-Series. Their service lives depend on the user environment and they can be optimized with regular inspection. As such, users are advised to conduct regular inspection and maintenance at least every year.

Conduct a visual inspection to find any damaged float or disconnected cable. If you find a scale used to measure the subject, remove it to facilitate the floating motion. The switches can be checked using a digital multimeter as follows.

- Set the switch of digital multimeter to the buzzer. To check, connect it to a cable terminal.
- It is normal for the buzzer to make a sound when the float is tilted at 120° or more from its vertical position. (The HQ-66S need tilt about 90° to sound the buzzer.)
- To check the contact with resistance, set the digital multimeter switch to Ω . Then, tilt the float to see if it is normal: if the digital multimeter indicates a 0Ω or a ∞ with the float on or off, respectively, it means that it is working fine.



Turn off the power of the product for maintenance.

Precautions for Installation


- Use the same standard flange or screws.
- Make sure washers are inserted between bolts and nuts to prevent loosening.
- Make sure gaskets are inserted between flanges.

(Select the gaskets in consideration of the temperature of the content and the pressure of the container.)

- Make sure to install the product and the cover before supplying the power.



Make sure that it is not subject to any impact when moving it.



- A. If it is installed at the inlet where the measuring subject flows into or where the subject is excessively shaken, it may malfunction.
- B. It is advisable to install it on a concrete wall as shown in the picture.
- C. Diameter "d" should be bigger than those of the float and weight.

Precautions for Removal

- Make sure to check the presence and level of the subject in the container before removing it.
- If the temperature is high, wear gloves to prevent burns.
- Disconnect the power first.
- Make sure that any O-ring or gasket is not damaged while opening or closing the cover of the product.

Safety and Environment


- Cautions for Use
 - Make sure to connect the product and container using the required tools.
 - Avoid causing large impacts to the product.
- Cautions for Wiring
 - Make sure to connect contacts with the correct terminals. (Refer to Wiring.)
- Disposal
 - Make sure to separate the terminal block and the main unit from the housing before wasting it. Pay special attention to the mercury switch because it can influence the environment.

Marking

- Product Identification
 - The label is attached on top and side of the product housing. The label states the model, serial number, working temperature, working pressure, and output of the product. The serial number is a unique manufacturing number.

HITROL CO., LTD.	
MODEL	
TAG NO.	
SER. NO.	
MAX. TEMP.	°C
MAX. PRESS.	kgf/cm ²
CONTACT RATING	
CONTACT FORM	
ENCLOSURE	
www.hitrol.com	
Made in Korea	

<Nameplate for ABS Housing>

LEVEL SWITCH	
TYPE :	TAG NO :
SWITCH FORM : <input type="checkbox"/> SPST <input type="checkbox"/> SPDT <input type="checkbox"/> DPDT	
SWITCH RATING : AC	V A
POWER : AC	V
MAX PRESS :	MAX TEMP :
 HITROL CO., LTD. <small>MADE IN KOREA</small>	

<Nameplate for SUS Housing>

User Training

Make sure that the temperature of the fluid does not exceed 60°C for a normal container, or 150°C for a high-temperature container. In addition, make sure that the ambient temperature of the housing is kept at -20 – +60°C.

Warranty and Contact**■ Warranty and Service**

This product is subject to a two-year warranty upon shipment and free service will be provided for any damage found under normal operating conditions. If troubles that occur are not due to product failure, service charge will apply.

You can request A/S from our website or by contacting our headquarters.

■ Headquarters, Factory, and Research Center (Contacts)

Address: Hitrol, 141, Palhakgol-gil, Jori-eup, Paju-si, Gyeonggi-do, Republic of Korea
(Palhakgol-gil 98)

HITROL CO., LTD. 141, Palhakgol-gil, Jori-eup, Paju-si, Gyeonggi-do, Korea

TEL: 031-950-9700 (Headquarters and A/S)

FAX: 031-943-5600 (Headquarters and A/S)